



10mm Radar Dish

B10-ACC-401

Please read these instructions fully before starting construction.

PVA or equivalent glue will be required to stick sections together.

Sand paper can be used to gently clean any joints.

A sharp modelling knife will be required to remove sections from the sprue. Please use knives with due care and remember to cut away from yourself at all times.

During the construction of this model, you may find it convenient to use pegs / elastic bands to hold pieces in place while you allow glue to dry.



Remove the pieces shown above from the sprue. Note some of these pieces are fragile so ensure the sprue points are fully cut through.



Glue the two main pieces together.



Glue the dish sections to their support.



Then glue the dish to the stand and pop the stand onto its base.



The finished radar