



6mm 4x4 Cross/Shops

B06-MW-105

Please read these instructions fully before starting construction.

PVA or equivalent glue will be required to stick sections together.

Sand paper can be used to gently clean any joints.

A sharp modelling knife will be required to remove sections from the sprue. Please use knives with due care and remember to cut away from yourself at all times.

During the construction of this model, you may find it convenient to use pegs / elastic bands to hold pieces in place while you allow glue to dry.



Take each of the wide wall sections and its brace piece (shown on the left). Glue the brace to the rear of the wall (shown on the right)



Take four of the shorter walls (shown above)



Attach the wide wall to the "roof", then slide the side walls into place on either side of it. Move around the building repeating this for each side.



Glue the decorative columns into place.



The completed building.