



BLOTZ

20mm Ruins #11 – Ruined Archway #2

B20-RU-011


Please read these instructions fully before starting construction.

PVA or equivalent glue will be required to stick sections together.


Sand paper can be used to gently clean any joints.

A sharp modelling knife will be required to remove sections from the sprue. Please use knives with due care and remember to cut away from yourself at all times.

During the construction of this model, you may find it convenient to use pegs / elastic bands to hold pieces in place while you allow glue to dry.




Remove the front wall section and small wall piece from the sprue (as shown above)



Glue them together.



Attach the base.



Take the back wall and other side of the short wall.



Glue them into position.



The finished model.

Once constructed, we sprayed our model with a matt black car undercoat aerosol, then applied a heavy drybrush of a dark blue/grey colour emulsion.

After that had dried we applied a lighter drybrush of a pale grey colour, then followed this by a very light drybrush of an almost white emulsion.

All our emulsion paints are DIY store colour-test pots.