



20mm Bunkbeds

B20-ST-114

Please read these instructions fully before starting construction.

PVA or equivalent glue will be required to stick sections together.

Sand paper can be used to gently clean any joints.

A sharp modelling knife will be required to remove sections from the sprue. Please use knives with due care and remember to cut away from yourself at all times.

During the construction of this model, you may find it convenient to use pegs / elastic bands to hold pieces in place while you allow glue to dry.



Each set of bunkbeds is formed from the pieces shown above.



Glue the side bars to each bunk.



Then glue the uprights into place.



The completed bunk beds.