



## 28mm Knotwork Plinth

**B28-ST-141**

Please read these instructions fully before starting construction.

PVA or equivalent glue will be required to stick sections together.

Sand paper can be used to gently clean any joints.

A sharp modelling knife will be required to remove sections from the sprue. Please use knives with due care and remember to cut away from yourself at all times.

During the construction of this model, you may find it convenient to use pegs / elastic bands to hold pieces in place while you allow glue to dry.



Remove the base and four sides (shown above) from the sprue.



Glue the sides to the base so that they form an open topped box.



Glue the top of the open box...



Glue one "L" piece into place. Note it is flush on the left and extends out by 2mm on the right.



Glue the rest of the "L" shapes into place around the plinth.



Add the knotwork panels so that there is a very small gap all the way around them.



Glue the top piece into place.



The finished knotwork plinth.  
This was sprayed black then drybrushed with various shades of grey.